

### 線位表






CN1 — CN2	CN1 — CN2
01 — 01	11 — 11
02 — 02	12 — 12
03 — 03	13 — 13
04 — 04	14 — 14
05 — 05	15 — 15
06 — 06	16 — 16
07 — 07	17 — 17
08 — 08	18 — 18
09 — 09	19 — 19
10 — 10	铁壳 — 铁壳

Arvanics Corporation

型番：ADHDM/HDF-1

单位：mm





### 接線表

CN1	—	CN2	CN1	—	CN2
01	—	01	11	—	11
02	—	02	12	—	12
03	—	03	13	—	13
04	—	04	14	—	14
05	—	05	15	—	15
06	—	06	16	—	16
07	—	07	17	—	17
08	—	08	18	—	18
09	—	09	19	—	19
10	—	10	铁壳	—	铁壳

Arvanics Corporation

型番：ADHDM/HDF-2

単位：mm

